

For Beautiful Stitching on Fine Leathers









ORGAN® NEEDLES CUTTING POINT Series

A wide variety of designs are possible

Straighter Stitching

design, the needle is stronger. Furthermore needle deflection that causes skipped stitched has been significantly reduced.

With the new improved



Consistant Loop Formation

For consistant loop formation, we adapted our unique Cliff Scarf to make enough space between the thread and needle.



Thick Threaded Designs possible

By making the needle eye bigger, the normal flament thread #5 can now be used with needle size #21. As well flament thread #0 can be used with needle size #23.



NORMAL							
SYMBOL	-\bigcip_\top\	- 	S	P	D	- D I	TQ
POINT			V	V			
STITCH							

Introducing the new expanded lineup of small cutting point

Marie Control of the	introducing the new expanded intemportal eatting point						
SMALL CUTTING POINT(M)							
SYMBOL	→ → M-LL	- ⊘ → M-LR	M-S	M-P	- → M-D	- (→)→ M-DI	
POINT				W	V		
STITCH							

Packaging

-10pcs-DP x 17LL Size 21M

CUTTING POINT Series

SYSTEM	7 8 9 10 11 12 13 14 16 18 19 20 21 22 23 24	25 FORMER SYSTEM
DP×17LL*		DP×16N
DP×17LR*		DP×16LR/DP×17LR
DP×17S		
DP×17P*		DP×16
DP×17DIA*		DP×17DIA
DP×17TQ		
DP×35LL	[2018] 1812년 1	
DP×35LR		
DP×35S		
DP×35P		
DP×35D		
DP×134LL*		PF×134LL
DP×134LR*		PF×134LR
DP×134S*		PF×134KS
DP×134P*		PF×134P
DP×134DIA*	TO THE STATE OF THE PARTY AND	DP×8
DP×134D*		PFX 134D

^{*} Please Note: we have renamed the system.



^{*}The arrows show the direction to thread the needle

^{*}When placing an order for the small cutting point, please indicate with an M after the size number.